



Cordless Roller Shade with Easy Spring Plus

Installation Instructions








Installation Instructions 1-1/4" (32mm) Single System (Inside & Outside Mount)


Step 8. Install Mounting Brackets & Headrail (Mounting brackets should be installed every 18" starting from no more than 2" in from the end of the headrail)


For Headrail RE0080110

Inside Mount



Outside Mount





For Headrail RE0080810

Inside Mount





Outside Mount





For Cassette 100 & 120

Cassette 120 shown Mounting brackets for Cassette 100 are slightly different

Outside Mount














Step 9. To Adjust spring and stop: 9a. Brackets with adjuster wheel 9b. Brackets without adjuster wheel




Spring: Turn Clockwise to increase the speed of the shade, and counterclockwise to reduce the speed the shade goes up.



Stop: Turn Clockwise to lower stop, and counterclockwise to raise

Spring: Use screwdriver and turn Clockwise to increase the speed of the shade, and counterclockwise to reduce the speed the shade goes up.



Stop: Use screwdriver and turn Clockwise to lower stop, and counterclockwise to raise stop





Installed Shade

Single Shade Shown



Cassette System

